

Materials for Taking off the Stratum

Resin	:	Tomac NS-10 (Polyurethane)
Cloth	:	reinforce the resin
Brush	:	apply the resin on the stratum
Mask	:	for the health care
Gloves	:	for the health care
Cup	:	subdivide the resin
Scissors	:	cut the cloth



Technical Process of Taking off the Stratum

- 1 Cleaning and leveling the surface of the stratum.



- 2 If the stratum is dry, give moisture by a spray, but the stratum is wet, it need not .
- 3 Apply the resin on the stratum by a brush.



- 4 Put the cloth on the resin for reinforcement.



- 5 Apply the resin on the cloth by a brush.
- 6 Harden the resin for 1-2 hours in the summer season. But in the winter season, it need 12-24hours.
- 7 Take off the stratum, thickly.



- 8 Clean the stratum by brush and water.



- 9 Dry the stratum.





10 Spray the resin on the surface of the stratum.

11 Make the panel of the stratum.

